

QUICK REFERENCE GUIDE



PASSION ENGINEERED



Foreword

We are pleased to welcome you to the family of Perodua owners. As you know, the performance and durability of a vehicle depends, to a large extent, upon the way it is maintained and driven.

This Quick Reference Guide is a summary of basic vehicle operations. It contains brief description of fundamental operations so you can locate and use the vehicle's main equipment quickly and easily.

The Quick Reference Guide is not intended as a substitute for the vehicle Owner's Manual.

Full Owner's Manual can be downloaded from Perodua Official Website (www.perodua.com.my) or Perodua e-Owner's Manual page (<https://eownersmanual.perodua.com.my>).

For full awareness of your rights under the warranty granted and limitation set, please refer to the Warranty Booklet in Perodua e-Owners Manual page.

We strongly encourage you to review the Owner's Manual and any other supplementary manuals so you will have better understanding of your vehicle's capabilities and limitations.



If you have any questions, feel free to contact your authorised Perodua Service Centre. We are ready to provide qualified service and assistance

PERODUA SALES SDN. BHD.



©2021 PERODUA SALES SDN. BHD.

All rights reserved. This material may not be produced or copied, in whole or in part, without the written permission of Perodua Sales Sdn. Bhd.

Scan the QR code to visit the e-Owner's Manual Website



Scan the QR code to download the e-Owner's Manual Mobile App



DISCLAIMER

The information in this manual is subject to change without notice. No part of this manual may be reproduced or transmitted in any form or by any means electronic or mechanical including photocopying, recording or information storage and retrieval systems for any purpose other than personal use without our written permission.

While every effort has been made to ensure that the information and contents in the manual are complete, accurate, up-to-date, reliable and non-misleading, we cannot be held responsible for mistakes, inaccuracies, or errors found in the manual. Nor is any liability assumed for damages resulting from the reliance and use of information contained herein. This manual is provided without any representation or warranties, express or implied.

PERODUA SALES SDN. BHD.

INDEX

OVERVIEW

INSTRUMENT PANEL	1
INSTRUMENT CLUSTER	2
INDICATOR SYMBOL	3
SMART ENTRY	5
PUSH START/STOP BUTTON	8
FUEL TANK DOOR RELEASE AND CAP RELEASE	10
HOOD RELEASE	10

FEATURES & OPERATIONS

CLOCK	11
SEATS	13
TILT STEERING	14
SIDE VIEW MIRRORS	15
POWER WINDOW	15
OPERATION OF CVT	16
PARKING BRAKE	16
LIGHTS, TURN SIGNALS AND WIPERS	17
ADVANCED SAFETY ASSIST (ASA)	20
PRE-COLLISION WARNING	21
PRE-COLLISION BRAKING	21
PEDAL MISOPERATION CONTROL	22
LANE DEPARTURE WARNING (LDW)	22
LANE DEPARTURE PREVENTION (LDP)	23
FRONT DEPARTURE ALERT	23
ADAPTIVE CRUISE CONTROL (ACC)*	24
LANE KEEP CONTROL (LKC)*	27
IDLING STOP SYSTEM (eco IDLE)	28

FEATURES & OPERATIONS

(continued)

HILL - START ASSIST SYSTEM	30
BLIND SPOT MONITOR (BSM)*	31
REAR CROSS TRAFFIC ALERT (RCTA)*	32
FRONT & REAR CORNER SENSOR	33
REVERSE CAMERA*	33
VSC & TRC SYSTEMS	34
EMERGENCY STOP SIGNAL	35
ELECTRONIC TOLL COLLECTION SYSTEM*	36
AIR CONDITIONING SYSTEM	37
AUDIO	38
BLUETOOTH OPERATION	39
STEERING WHEEL SWITCH*	40
USB SOCKET*	40
POWER SOCKET	40


SAFETY & EMERGENCY

FLOOR MAT INSTALLATION	41
SEAT BELTS	41
FRONT SEAT BELT PRETENSIONERS	41
SRS AIRBAGS	42
TYPE OF CHILD RESTRAINT SYSTEM	42
DOOR LOCK	43
CHILD LOCK	43
JAM PROTECTION FUNCTION	44
IF VEHICLE BREAKS DOWN	44
TOOL, JACK AND TYRE LOCATION	45

* : The equipment may vary according to the vehicle grade and options.

OVERVIEW

INSTRUMENT PANEL




- | | |
|------------------------------------|-------------------------------------|
| ① Turn signal lever | ⑬ Engine start/stop button |
| ② Headlight switch | ⑭ USB socket |
| ③ Daytime Running Lights (DRL)* | ⑮ Power socket |
| ④ Meters | ⑯ Air conditioning |
| ⑤ Wiper and washer switch | ⑰ Side mirror switches* |
| ⑥ Audio* | ⑱ Advanced Safety Assist OFF switch |
| ⑦ Hazard light switch | ⑲ VSC OFF switch |
| ⑧ SRS air bags for front passenger | ⑳ eco IDLE OFF switch |
| ⑨ Glove compartment | ㉑ AHB switch* |
| ⑩ Hood lock release lever | ㉒ Headlight levelling switch |
| ⑪ SRS air bags for driver | ㉓ Central door lock switch |
| ⑫ Tilt steering lock release lever | ㉔ Front Corner sensor switch* |


* : The equipment may vary according to the vehicle grade and options.

INSTRUMENT CLUSTER

LCD MULTI-INFORMATION DISPLAY*



TFT COLOUR MULTI-INFORMATION DISPLAY*
























- | | |
|-----------------------------|--|
| ① Tachometer | ⑧ TFT colour multi-information display |
| ② Multi-information display | ⑨ Driving assist display |
| ③ Fuel gauge | ⑩ Clock |
| ④ Shift position display | ⑪ Content display |
| ⑤ Speedometer | ⑫ ODO/Trip information |
| ⑥ Display change button | ⑬ Service information reminder |
| ⑦ Clock adjustment button | ⑭ Eco drive assist lighting |

























* : The equipment may vary according to the vehicle grade and options.

INDICATOR SYMBOL

For details, refer to “Warning lights and Indicators” in Section 2 Owner’s Manual.

	Brake system warning light		Lane Departure Warning activated light
	Battery charge warning light		Master warning light*
	Low engine oil pressure warning light		ACC warning light (yellow)/ACC indicator (green)*
	High engine coolant temperature warning light (red)/Low engine coolant temperature indicator (blue)		LKC warning light (yellow)/LKC indicator (green)*
	Engine malfunction warning light		Slip indicator
CVT	CVT warning light		eco IDLE OFF indicator
	SRS airbags/pretensioner warning light		eco IDLE indicator
	ABS warning light		BSM OFF indicator*
	Electric power steering warning light (red/yellow)		RCTA OFF indicator*
	Key-free system warning light		Brake override system warning light
	AHB warning light (yellow)/AHB activated light (green)*		Hands-free driving warning light*
	Advanced Safety Assist OFF indicator		Door ajar warning light

* : The equipment may vary according to the vehicle grade and options.

	Low fuel warning light		Eco driving indicator*
	Driver seat belts reminder light		Side-view mirrors indicator*
	Front passenger seat belts reminder light [※]		Advanced Safety Assist operation indicator
	Rear seat passenger seat belts reminder light [※]		Lane recognition indicator*
	Parking brake warning light		Steering operation support activated light*
	Service information reminder		Lane Departure Warning OFF indicator
	Turn signal indicator		Cruise Control indicator*
	Headlights high beam indicator		ACC SET indicator*
	Security indicator		Leading vehicle indicator*
	Tail lights indicator		ACC OFF indicator*
	VSC OFF indicator		LKC OFF indicator*
	TRC OFF indicator		Power mode indicator*

If indicator does not turn off within a few seconds of starting engine, there may be a malfunction. Have the system checked by an authorised Perodua Service Centre.

※ : This light illuminates on the center panel.

* : The equipment may vary according to the vehicle grade and options.

SMART ENTRY

LOCKING OPERATION



Press once to lock

UNLOCKING OPERATION



- Press once to unlock driver door
- Press twice to unlock all doors


BACK DOOR

UNLOCKING OPERATION



Press more than 1 second to unlock.

PANIC ALARM BUTTON




Press and hold.




- To activate :
 - Press ④ more than 1 second. (Within 10 meters distance around)
- To stop :
 - Press ①, ②, or ④.
 - The alarm will sound for 45 seconds if any of these buttons are not pressed.

EMERGENCY KEY




Emergency key




Push the knob downwards to release the emergency key.

Use the emergency key if the Smart Key battery is weak or if the Smart Entry function does not operate properly.

LOCK / UNLOCK DOOR



UNLOCK BACK DOOR




Operating range may vary by surrounding conditions.

- (i) Key-free: Within 3 meter from centre of vehicle.
- (ii) Request switch: When the smart key is within approximately 80 cm from outer door handle.

DOOR AUTO LOCK AND UNLOCK FUNCTION

These functions designed to automatically lock or unlock all doors depending on the vehicle's situations.


Auto-lock functions



All doors locked when :

- Vehicle speed more than 20 km/h (initial setting).
- Shift lever moved from P while the engine is running.

Auto-unlock functions




All doors unlocked when :


- Engine switch is set to 'ACC' or 'OFF' after running at a speed of 20 km/h or more (initial setting).
- Shift lever is in P

PUSH START/STOP BUTTON


PUSH START SYSTEM




TO START ENGINE



TO STOP ENGINE




TO CHANGE ENGINE SWITCH MODE




When brake pedal is not depressed, pressing the Push Start/Stop Button will change the engine mode.

SWITCHING ENGINE ON WHEN SMART KEY BATTERY IS WEAK




- 1 Move the shift lever to 'P' while depressing the brake pedal.




- 2 Touch the Smart Key to the engine switch until the indicator lights up in green and the alarm will deactivate.
- 3 Press the engine switch.


FUEL TANK DOOR RELEASE AND CAP RELEASE



Pull up the opener and open the fuel filler door.




Turn and open the cap slowly. To close after refill, turn the cap opposite until clicking sound can be heard.




During filling, place the cap on the hanger.


HOOD RELEASE



Pull the hood release lever.



Lifting the lever and open the hood.




Unlatch and insert the supporting rod into the slot.

FEATURES & OPERATIONS

CLOCK

LCD multi-information display*



- ① To set the hour (H).
- ② To set the minutes (M).
- ③ To set the minutes to '00'.
 - Press and hold button ① and ② together at the same time.

TFT colour multi-information display*


Time and date setting



- ① Press ENTER buttons to switch to Setting Menu.
- ② Press \wedge \vee buttons to select 'Time and Date' and press ENTER button.
- ③ Time
 - For Hour/minutes, after \blacksquare displayed, press \wedge \vee buttons to set minutes and hour, then press ENTER.
 - For 12H/24H will switch between '12H' (12 hour display) and '24H' (24 hour display) every time the ENTER button is pressed.
 - Regardless of 12H/24H settings, the clock will be displayed in a 24-hour format during adjustment.
- ④ Date
 - For 'Sort by Date', after \blacksquare is displayed, press the \wedge \vee buttons to select the display order of the date and pressing the ENTER button again.
 - For "Day", "Month", and "Year", after \blacksquare displayed, press \wedge \vee buttons to set day, month and year, then press ENTER.

* : The equipment may vary according to the vehicle grade and options.

Clock display setting




- ① Press ENTER buttons to switch to setting menu.
- ② Press \wedge \vee buttons to select 'Display Setting' and press ENTER button.
- ③ Switch between the screens in 'Display Setting' either by pressing and holding or pressing the \wedge \vee buttons several times. Select 'Clock Display Type' and press ENTER button.
- ④ Press \wedge \vee buttons to select 'Clock 1' or 'Clock 2' and press ENTER button.

SEATS


ADJUSTING THE SEATS

Front seats



- ① Adjusts seat positions.
- ② Adjusts seat back reclining positions.
- ③ Adjusts seat height. (Driver's seat only)



Rear seats




- ① Adjust reclining positions.
(Two stages reclining)

FOLDING THE SEAT BACK DOWN

Rear seats




- ① Store seat belt buckle.
- ② Lower the headrest.



- ③ Pull the lever.
- ④ Fold down the seat back.


ADJUSTING THE HEAD RESTRAINTS

Front seats




- ① Up
- ② Down

Rear seats*




- ① Up
- ② Down

Installing




Align the head restraint and push release button while push the head restraint down.

Adjusting (front seats)




Adjusting its centre align with your ears.

TILT STEERING



- ① Hold the steering and pull the lever up.




- ② Adjust steering wheel and push the lever down to lock.

* : The equipment may vary according to the vehicle grade and options.


SIDE VIEW MIRRORS

TO ADJUST



- ① Set the switch to left or right.
- ② Push the switch to adjust the mirror.



TO FOLD



- ① To fold mirrors.
- ② To open mirrors.
- ③ Automatic fold and open mirrors.

This component is enabled when the engine switch is in "ACC" or "ON" mode.

POWER WINDOW





Automatic operation

Push the switch down or pull it completely up and release to fully open or close. To stop window partially, push the switch lightly in the opposite direction during opening or closing.

OPERATION OF CVT


CVT TRANSMISSION



P	Parking or start engine
R	Reverse
N	Neutral
D	Normal driving
S	Driving on a slope
B	Driving down a steep hill

- : Operate with the brake pedal depressed and the shift lever button pressed with the engine switch set to IGNITION ON mode.
- : Operate with the shift lever button pressed.
- : Operate without the shift lever button pressed.



TO SELECT DRIVING MODE



Power mode : Enables the vehicle to accelerate more by increasing the engine power. Suitable when driver wants to quickly speed up while driving.

Normal mode : Suitable for normal driving which can be defined as driving under optimal condition such as good weather, clear traffic, and good vehicle and road condition.


PARKING BRAKE




- ① To engage : Pull brake lever while pressing brake pedal.
- ② To release : Slightly pull brake lever up and all the way down while pressing the lever button.

LIGHTS, TURN SIGNALS AND WIPERS

TURN SIGNAL LEVER




- ① Left turn.
- ② Lane change (left).
- ③ Lane change (right).
- ④ Right turn.





HEADLIGHT SWITCH

- Type 1




- Type 2*




- ① Clearance lights, tail lights, license plate light.
- ② Lights on.
- ③ Lights off.
- ④ Lights on/off automatically.
- ⑤ High beam.
- ⑥ Headlight flasher.

FOLLOW ME HOME SYSTEM



- ① Switch 'OFF' engine switch.
- ② Pull lever towards self.
- ③ Release light switch in O or AUTO.


HEADLIGHT LEVELLING SWITCH*




- ① Upward adjustment.
- ② Downward adjustment.

* : The equipment may vary according to the vehicle grade and options.

DAYTIME RUNNING LIGHT (DRL)*



Daytime running light




Daytime running light operation condition:



- Engine is ON
- Headlight switch position in AUTO
- Parking brake release

AUTO HIGH BEAM (AHB)

AHB helps to switch the headlights automatically into high beam or low beam depending on the surroundings brightness. (e.g. lights from street lamps, preceding vehicle or opposite directions vehicles.)



To activate, make sure to :

- ① Switch 'ON' the engine switch.
- ② Set lever to original position.
- ③ Set light switch to  (type 1),  or AUTO (type 2).
- ④ Turn 'ON' AHB switch.
- ⑤ Do not set front wiper to high speed operation.

Automatic high beam condition :


- Vehicle speed : 30 km/h or more.
- Vehicle's front area : Dark.
- No vehicle is coming in opposite direction.
- Street lamps in front : Dark.

Automatic low beam condition :

- Vehicle speed : 20 km/h or less.
- Vehicle's front area : Bright.
- There is vehicle coming in opposite direction.
- Street lamps in front: Bright.

* : The equipment may vary according to the vehicle grade and options.

FRONT WIPERS AND WASHER




During intermittent (INT) operation, the interval becomes shorter as the driving speed rises.

ADVANCED SAFETY ASSIST (ASA)


ASA is a system designed to support the driver's awareness, decision making and vehicle operation contributing to a safe driving experience.

STEREO CAMERA



- A stereo camera mounted in front of the inside rear view mirror which detect vehicle up to about 70 m (pedestrian up to 45 m) in front.
- The stereo camera will not operate properly if the wind shield view in front of the camera is obstructed by something, dirt, foggy, sticker etc.

ASA OFF SWITCH




ASA OFF indicator light will illuminate at the meter panel. Every time you start the engine by the engine switch operation, ASA function will return to ready state.

Refer to the Owner's Manual (Section 4) for additional information on operation, settings adjustments, limitations and precautions before attempting to use it.

PRE-COLLISION WARNING

Alert the driver when the stereo camera recognizes the high collision risk during day and night.




The diagram shows a small car on the left and a larger car on the right, with an arrow pointing from the small car to the larger car. Above the small car, there are two speech bubbles: one containing a starburst icon and another containing the text 'Pipipipipipi'.

- When the system determines if there is a risk of collision, it will alerted and urged the driver to take evasive action by the buzzer and display.
- This function operates when the vehicle speed and speed difference between the front obstacles are :
4-120 km/h (vehicles, two-wheeled vehicles)
4-60 km/h (pedestrian)

PRE-COLLISION BRAKING

Control the brakes to assist in avoiding collision as well as contributing in mitigating collision damage during day and night.



The diagram shows a small car on the left and a larger car on the right, with an arrow pointing from the small car to the larger car. Above the small car, there are two speech bubbles: one containing a starburst icon and a warning triangle icon, and another containing the text 'Pipipipipi...'.


- If the system recognizes the front obstacles and determines that there is a high collision risk, it will change buzzer and control brakes.
- This function operates when the vehicle speed and speed difference between the front obstacles are :
4-120 km/h (vehicles, two-wheeled vehicles).
4-60 km/h (pedestrian).
- If the brake pedal is depressed under following conditions, it helps to decelerate with more braking force than normal :
30-120 km/h (vehicles, two-wheeled vehicles).
30-60 km/h (pedestrian).

- Continuously press the brake pedal to continue stop the vehicle because the vehicle will slowly start moving after 1.5 seconds.
- The operation cancelled if it determines low collision risk made by the driver such as pressing the brake pedal or operating the steering wheel.

Refer to the Owner's Manual (Section 4) for additional information on operation, settings adjustments, limitations and precautions before attempting to use it.

PEDAL MISOPERATION CONTROL

This function assist driver in avoiding collision by controlling engine output when the driver accidentally press the accelerator pedal.




The systems activates by following conditions :

- Stereo camera recognizes obstacle 4 m ahead.
- Pressing wrong pedal while driving slowly approximately 10 km/h or slower.


If the accelerator is pressed accidentally at approximately 4 km/h or less, the driver will be alerted by the buzzer and display.

LANE DEPARTURE WARNING (LDW)

Alert the driver when there is a risk of the driver unintentionally depart from the vehicle lane.



Lane recognition indicator*



The system activates by following conditions :


- Engine switch is 'ON'.
- Vehicle speed : 60 km/h or more.
- Lane Departure Warning OFF indicator is off.
- Turn signal indicator off for 4 seconds after the turn signal indicator is turned off.
- Vehicle lane width approximately 2.5 to 4.2 m.

Refer to the Owner's Manual (Section 4) for additional information on operation, settings adjustments, limitations and precautions before attempting to use it.

* : The equipment may vary according to the vehicle grade and options.


LANE DEPARTURE PREVENTION (LDP)

Provides small steering force to the steering wheel to avoid the vehicle departing from the vehicle lane by alerts using buzzer and display.



FRONT DEPARTURE ALERT

Alerts the driver when the vehicle in front has moved.



Shift position is other than **P** & **R** and distance between the stopped preceding vehicle and own vehicles is within about 10 meter.


Refer to the Owner's Manual (Section 4) for additional information on operation, settings adjustments, limitations and precautions before attempting to use it.

ADAPTIVE CRUISE CONTROL (ACC)*

This system consist of two modes :

- Distance control mode : Detect the presence of front vehicle (by stereo camera) and automatically accelerates or decelerates based on the speed change by the front vehicle.
- Constant speed control mode : Allow driver to drive at constant speed set by the driver.


System components



Refer to the Owner's Manual (Section 4) for additional information on operation, settings adjustments, limitations and precautions before attempting to use it.


* : The equipment may vary according to the vehicle grade and options.

DISTANCE CONTROL MODE




- ① Constant speed driving (no vehicle in front).
- ② Decelerated driving-cruise control driving (front vehicle slower than set speed).
- ③ Accelerated driving (slower speed front vehicle no longer in front).

Setting the set speed (Distance control mode)



- ① Press ACC main switch (the display will be displayed as '___ km/h').
- ② Accelerate/decelerate using accelerator to the desired speed (30 km/h or higher).
- ③ Press '+SET' switch.

Changing the set speed (Distance control mode)




Refer to the Owner's Manual (Section 4) for additional information on operation, settings adjustments, limitations and precautions before attempting to use it.

CONSTANT SPEED CONTROL MODE


This mode allow vehicle moves at a constant speed set by driver without matching the changes in speed made by the vehicle in front.

Setting the speed (Constant speed control mode)



- ① Press and hold ACC main switch for 2 seconds or longer (the display will displayed as ' _ _ km/h').
- ② Accelerate/decelerate using accelerator to desire speed (30 km/h or higher).
- ③ Press '- SET' switch


Changing the set speed (Constant speed control mode)



Refer to the Owner's Manual (Section 4) for additional information on operation, settings adjustments, limitations and precautions before attempting to use it.

LANE KEEP CONTROL (LKC)*


This system assist the driver's steering operation to ensure the vehicle drives in the current lane by recognizing the white or yellow lines on the left or right of the vehicle using the stereo camera. The LKC does not operate when the ACC is not active.



The driver is informed on LKC operation by the indicator in meter and display. The system activates by following conditions.


- Vehicle speed : 60 km/h or more.
- ACC (distance control mode) : 60 km/h or more
- ACC (set speed) : 60 km/h or more
- LKC indicator : Lights up

LKC indicator



- ① LKC OFF indicator.
- ② Lane recognition indicator.

To set or cancel the function



While the ACC (Distance control mode) is operating.

- ① Press the LKC switch to switch ON.
- ② Press the LKC switch again to switch OFF.




Refer to the Owner's Manual (Section 4) for additional information on operation, settings adjustments, limitations and precautions before attempting to use it.

* : The equipment may vary according to the vehicle grade and options.

IDLING STOP SYSTEM (eco IDLE)

ECO


The 'eco IDLE' is a system that stop and restart the engine with the brake pedal without using the engine switch while the vehicle stops at a red traffic light or an intersection.




- ① When conditions for 'eco IDLE' mode are fulfilled during driving, the 'eco IDLE' ready indicator turns on in green (standby state).
- ② While the shift lever is in D, depress the brake pedal and stop your vehicle for 'eco IDLE' mode. The indicator will remain on in green during 'eco IDLE' mode.
- ③ The engine restarts when foot is released from the brake pedal. The 'eco IDLE' ready indicator will turn off.
- ④ The 'eco IDLE' ready indicator turn on in green again after conditions for 'eco IDLE' mode are fulfilled.

Refer to the Owner's Manual (Section 4) for additional information on operation, settings adjustments, limitations and precautions before attempting to use it.

'eco IDLE' may not operate normally under the following conditions. Have the vehicle checked by an authorized Perodua Service Centre.



The interior light turns on when the driver's door is closed and does not turn on when the driver's door is opened.



Door ajar warning light turns on when the driver's door is closed and does not turn on when the driver's door is opened.






Seat belt reminder light flashes when driver's seatbelt is fastened, and/or does not flash when driver's seat belt is not fastened.

Refer to the Owner's Manual (Section 4) for additional information on operation, settings adjustments, limitations and precautions before attempting to use it.


HILL - START ASSIST SYSTEM

Hill-Start Assist System helps to prevent the vehicle from rolling back when starting up again from a stopped position on an incline.




BLIND SPOT MONITOR (BSM)*


BSM overview : Assists driver when changing lanes.



BSM function : Detects the next vehicle running in the next lane using radar sensor and informs driver using side-view mirror indicator and buzzer.



BSM function effective range




Refer to the Owner's Manual (Section 4) for additional information on operation, settings adjustments, limitations and precautions before attempting to use it.


* : The equipment may vary according to the vehicle grade and options.

REAR CROSS TRAFFIC ALERT (RCTA)*


RCTA overview : Assist driver when reversing.



RCTA function



RCTA function effective range



For fast vehicles, the buzzer will sound when the vehicle is further away.


Approaching vehicle speed	① Alert distance (estimate)
Approximately 28 km/h (fast)	Approximately 20 m
Approximately 8 km/h (slow)	Approximately 5.5 m

Refer to the Owner's Manual (Section 4) for additional information on operation, settings adjustments, limitations and precautions before attempting to use it.


* : The equipment may vary according to the vehicle grade and options.

FRONT & REAR CORNER SENSOR


SONAR LOCATIONS AND TYPES



FRONT CORNER SENSOR SWITCH



REVERSE CAMERA*



Any object under the bumper or near both ends of the bumper are out of the reverse camera display range.

* : The equipment may vary according to the vehicle grade and options.

VSC & TRC SYSTEMS


Vehicle Stability Control (VSC)

Keeps the vehicle stable during sudden turns or on slippery roads.


Traction Control (TRC)

Assists with keeping the stability of the vehicle when accelerating on slippery roads.

VSC & TRC OPERATION




- These situations may arise depending on road, tyre and weather conditions.
- The vehicle is more secure if it is equipped with ABS (Anti-lock Braking System) & EBD (Electronic Brake force Distribution.)




IMPORTANT:

Even when VSC & TRC are operation, there are limits to the systems' traction and stability control. Dangerous driving may still cause accidents.



EMERGENCY STOP SIGNAL

Emergency stop signal system reduces the risk of collision by automatically flashing the hazard lights when the brakes applied suddenly to alert the vehicle behind.




Emergency stop signal operating conditions :

- Hazard warning signal light is OFF.
- Vehicle speed is about more than 60 km/h.
- The system determines from the vehicle deceleration and the pressed brake pedal that involve in sudden braking or when ABS system is activated.

Driver is obliged for a safe driving and avoid unnecessary sudden braking.

ELECTRONIC TOLL COLLECTION SYSTEM*




* : The equipment may vary according to the vehicle grade and options.


AIR CONDITIONING SYSTEM

Make sure the ignition switch is ON to operate the air conditioner blower.


TURN ON AIR CONDITIONER




TEMPERATURE CONTROL



BLOWER FAN SWITCH




SET MEMORY




AUDIO

(Type 1)



Refer to the Owner's Manual (Section 5) for more details.

(Type 2)




Refer to the Owner's Manual (Section 5) for more details.

- | | |
|-------------------------------------|---|
| ① Power/Mode button | ④ Equalizer/clock button |
| ② Auto store/Select (AS-SEL) button | ⑤ Volume button |
| ③ Mute button | ⑥ Clock button (Type 1)/
Bluetooth button (Type 2) |

BLUETOOTH OPERATION

Type 1 & 2



- ① Press and hold Bluetooth button for 5 seconds until beep sound.
- ② LCD will display "PAIRING" and "📶" will flashing.
- ③ Confirm default passkey "0000" in mobile phone.
- ④ LCD will display "CONNECTED" and "📶" will stop flashing.

Refer to the Owner's Manual (Section 5) for more details.

For LCD display type




- ① Select 'Bluetooth' button on main menu screen.
- ② Select 'Pairing' button to enter into pairing mode.
- ③ Use mobile phone to search for new bluetooth device mode.
- ④ Confirm the 6-digits passkey and press 'YES'.
- ⑤ Select 'OK' at mobile phone if the passkey is same.
- ⑥ LCD will display "CONNECTED" and ready to use.



Refer to the Multimedia Manual for more details.

STEERING WHEEL SWITCHES*




- ① Audio remote control switches*1
- ② Meter control switch
- ③ Phone switch*1
- ④ Voice command for smartphone link*1

- ⑤ LKC switch
- ⑥ ACC switch
- ⑦ Driving mode switch

*1: Refer to the Multimedia Manual for more details.


USB SOCKET*

Front




• For charging only.

Rear



• For charging only.



POWER SOCKET



* : The equipment may vary according to the vehicle grade and options.

SAFETY & EMERGENCY


FLOOR MAT INSTALLATION




Before driving, ensure that the floor mat is installed securely in the correct position.

SEAT BELTS


Fasten



Unfasten




FRONT SEAT BELT PRETENSIONERS



- Actuated when subjected to a strong impact from the front.
- Seat belt will instantly retract to secure the upper body of occupant.

SRS AIRBAGS



- ① SRS driver airbags/front passenger airbag (reduce impact of head and chest).
- ② SRS side airbags (reduce impact to the chest of front seat passenger).
- ③ SRS curtain shield airbags (reduce impact to the head for front and rear passengers).

TYPE OF CHILD RESTRAINT SYSTEM

Infants seats



Toddlers seats




Junior seats



- This vehicle is equipped with ISOFIX child restraint system seat.
- The child restraint system should be properly installed on the rear seat.

DOOR LOCK




① Locks the door.

② Unlocks the door :


- Driver door
Pull the inside handle lever.
- Passengers door
Release locking knob and pull the inside handle lever.

CHILD LOCK



JAM PROTECTION FUNCTION



Jam Protection Function is only available for driver's window only. If an object caught between the window and window frame still closing, the window will open slightly and stop moving



- Turn engine switch "ON".
- Push and hold the power window switch down until window has opened completely.
- Hold the power window switch in the one - touch closing position.
- Continue holding the switch for a further 2 seconds after the window has closed completely.


Window Jam Protection will not activate if obstruction is too small.

IF VEHICLE BREAKS DOWN



- ① Turn on the emergency flasher.
- ② Evacuate the occupants.
- ③ Place a triangle hazard sign (50 m or more from vehicle's rear).
- ④ Evacuate to safe place.

TOOL, JACK AND TYRE LOCATION



- ① Tool bag.*
- ② Jack.
- ③ Spare tyre.

*Jack handle, wheel nut wrench, towing hook..

Refer to the Owner's Manual (Section 7) for tyre changing and jack positioning procedure.

The following Wireless Communication products in this vehicle is certified (Type Approved) by SIRIM under Communication and Multimedia Act 1998



Immobilizer equipment (body ECU)



Keyless entry systems / immobilizer
(smartkey transmitter),
Blind spot monitor systems



PERODUA

Building Cars People First™